



UNITED

**Inter-Core
Technology**

L A B O R A T O R I E S

The innovative Inter-Core Technology combines the staying power of proven block technology with the instant concentrated dosage of a granular active!

- The core of the **O₂ PLUS** consists of a special blend of granular actives that provide quick release oxygen into the waste stream within minutes!
- The **O₂ PLUS** outer shell also contains the oxygen generating actives. This block portion is designed to release the oxygen over an extended time (60-90 days).
- **O₂ PLUS** provides low level oxygen over an extended time – reducing odor generation, stimulating beneficial biological activity and biological waste degradation significantly.

Ideal for lift stations, mains, sumps, grease traps and many other stagnant water situations. The **O₂ PLUS** provides an initial slug dose and then continual source of actives to stimulate biodegradation of grease and other organic wastes. The slow release shell of the **O₂ PLUS** provides 60 – 90 days of grease and odor reduction.

- **O₂ PLUS** contains a micro-nutrient package to provide additional bacteria food source.
- Easy Installation with minimal ongoing attention.
- Reduces Odors
- Near Neutral pH
- Works at Temperatures of 48°F to 120°F

DIRECTIONS FOR USE:

The **O₂ PLUS** should be placed in the waste stream nearly vertically on the upstream end of the invert or vessel chamber.

Mains and Lift Stations: Dosage is based on flow. Under 50,000 GPD use 1 block; 50,000 to 100,000 GPD use 2 blocks.

Grease Traps, Sumps and Stagnant Water: 1 block per 500 gallons or part thereof.

Specific sites may need different dosages. Call your United sales representative for special application needs.

United 982

O₂ PLUS

Slow Release

with Inter-Core Technology
Patent Pending

KEEP OUT OF REACH OF CHILDREN.
CAUTION
SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USARIO: Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Flush eyes with cool water for at least 15 minutes while keeping eyelids open. If irritation persists, seek medical attention.

SKIN: Wash with soap and water. Launder clothing. If irritation or redness persists, seek medical attention.

INHALATION: Not applicable.

IF SWALLOWED: Thoroughly rinse mouth with water. Drink one or two glasses of water. Slight gastrointestinal discomfort may occur.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product.

HMIS® III CODE 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX Glasses and Gloves	HEALTH	0
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	B

 Manufactured and Printed in U.S.A.